

AVerStreamEngines for GL310 Usage

v1.3.0.15 - 2018.09.10

Setup:

1. Install stream engine.
2. Launch Stream Engine on desktop.
3. Select the resolution, such as 720p60, 1080p30 or others.
4. Recommend to leave the bitrate to maximal value because of the video quality.
5. Select recording path if you want to use the hardware encoding feature.

How to use:

1. Launch Stream Engine on desktop to check the signal status
2. Run OBS/Streamlabs OBS
3. Remove all original avermedia devices from every scenes
4. Add a Video Capture Device and select LGPLite stream engine
(Use the existing device for other scenes)
5. Leave the resolution as the device default
6. Set audio output to waveout

How to record or backup stream

1. Launch Stream Engine on desktop
2. Launch streaming software
3. Click start button on stream engine